

PERFECT SERVINGS™ POWDER DISPENSERS

Model: SM-PSPD-3-4V



PROGRAMMING THE UNIT



The above diagram is a representative of the programming module located at the upper right hand corner on the inside front of the door. This is the location for programming the unit. To begin:

- 1) Program **each** canister to **either** dispense a 'portion-controlled' serving **or** a 'press and hold to dispense' serving.

Programming for 'portion control':

- 1) Select a canister.
- 2) Locate the "Product Setting Guide", which is on the last page of this manual.
- 3) Using the "Product Setting Guide", locate the product being dispensed from the product listing depending on the RPM of your machine.
- 4) Review and write down the setting associated with the product you wish to dispense. This is the number that you will want to program into the unit.

- 5) Press and hold the 'Program' button on the programming display (inside the door). The display will read 00.0, and the unit will 'beep'. You will see "SET" appear in the window.
- 6) Press the button on the 'touch panel' on the front door that corresponds to the canister you are setting.
- 7) Press the up or down buttons on the programming display until the number corresponds to the one you found on the settings sheet (for the timed delivery of product).
 - a. Please note that the 'UP' and 'DOWN' buttons change the dispense time in .1 second increments.
- 8) Press the button on the 'touch panel' again. This will lock in the dispense time.
- 9) To set other buttons as 'portion control', repeat steps 1-8 above.

Programming for 'manual dispense' (press and hold):

- 1) Press the program button ONCE.
- 2) Press the proper selection button on the touch panel.
- 3) Use the up and down buttons to set the time on the display to 00.0.
- 4) Press selection button on the touch panel.
- 5) To set other buttons for 'manual dispense' repeat steps 1-4 above.

Product Setting Guide

	Serving Size		
<u>Product</u>	<u>8 oz Cup</u>	<u>10 oz Cup</u>	<u>12 oz Cup</u>
<u>Hot Beverages</u>			
Cappuccino	7.0 = 28g	9.0 = 35g	10.6 = 42g
Hot Chocolate	6.4 = 28g	8.0 = 35g	9.6 = 42g
Chai Tea	5.6 = 28g	7.0 = 35g	8.2 = 42g
<u>Cold Beverages</u>			
Restore Plus More™ Isotonics	3.8 = 21g	5.1 = 28g	6.4 = 32g
<u>Creamers</u>			
Regular Creamer	0.7 = 2g	1.0 = 3g	1.4 = 4g
Flavored Creamer	1.0 = 4g	1.5 = 6g	2.3 = 8.5g
<u>Sweeteners</u>			
Sugar	0.3 = 2g	0.4 = 2.5g	0.5 = 3g
Sugar Substitute	0.2 = 1g	0.2 = 1g	0.4 = 1.5g

For a complete manual, please contact United Food Group, Inc.